

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6A

KeyCode	KeyName	ENAV ENGINE	AV PLAYBACK ENGINE
0	0	DEFAULT OPERATIONS ARE NOT DEFINED NOTE 1)	WHEN AV DATA STREAM INCLUDES PCI DATA AND BUTTON IS DISPLAYED BY THE PCI DATA, PERFORM Button_Select_and_Activate (Button Number) FUNCTION CORRESPONDING TO NUMBER
1	1	DEFAULT OPERATIONS ARE NOT DEFINED	
2	2	DEFAULT OPERATIONS ARE NOT DEFINED	
3	3	DEFAULT OPERATIONS ARE NOT DEFINED	
4	4	DEFAULT OPERATIONS ARE NOT DEFINED	
5	5	DEFAULT OPERATIONS ARE NOT DEFINED	
6	6	DEFAULT OPERATIONS ARE NOT DEFINED	
7	7	DEFAULT OPERATIONS ARE NOT DEFINED	
8	8	DEFAULT OPERATIONS ARE NOT DEFINED	
9	9	DEFAULT OPERATIONS ARE NOT DEFINED	
10	A	DEFAULT OPERATIONS ARE NOT DEFINED	DEFAULT OPERATIONS ARE NOT DEFINED
11	B	DEFAULT OPERATIONS ARE NOT DEFINED	DEFAULT OPERATIONS ARE NOT DEFINED
12	PlayPause	DEFAULT OPERATIONS ARE NOT DEFINED	NOTE 4)
13	Stop	DEFAULT OPERATIONS ARE NOT DEFINED	PERFORM Stop() FUNCTION
14	FastForward	DEFAULT OPERATIONS ARE NOT DEFINED	PERFORM Forward_Scan(Speed) FUNCTION
15	FastRewind	DEFAULT OPERATIONS ARE NOT DEFINED	PERFORM Backward_Scan(Speed) FUNCTION
16	Prev	DEFAULT OPERATIONS ARE NOT DEFINED	PTT_Search(Current PTT Number-1) NOTE 5)

FIG. 6B

KeyCode	KeyName	ENAV ENGINE	AV PLAYBACK ENGINE
17	Next	DEFAULT OPERATIONS ARE NOT DEFINED	PTT_Search(current PTT number+1) NOT6)
18	Subtitle	DEFAULT OPERATIONS ARE NOT DEFINED	PERFORM Sub_picture_stream_Change(Sub-picture stream number, Display flag) FUNCTION
19	Angle	DEFAULT OPERATIONS ARE NOT DEFINED	PERFORM Angle_Change(Angle number) FUNCTION
20	Audio	DEFAULT OPERATIONS ARE NOT DEFINED	PERFORM Audio_stream_Change(Audio stream number) FUNCTION
21	RootMenu	DEFAULT OPERATIONS ARE NOT DEFINED	PERFORM Menu_Call(Root) FUNCTION
22	TitleMenu	DEFAULT OPERATIONS ARE NOT DEFINED	PERFORM Menu_Call(Title) FUNCTION
23	Up	PERFORM NAVIGATION OPERATION FOR SELECTING ELEMENTS OF MARKUP DOCUMENT ONTO WHICH FOCUS IS BROUGHT	PERFORM Upper_Button_Select() FUNCTION
24	Left		PERFORM Left_Button_Select() FUNCTION
25	Right		PERFORM Right_Button_Select() FUNCTION
26	Down		PERFORM Lower_Button_Select() FUNCTION
27	OK	PERFORM OPERATION FOR EXECUTING SELECTED ELEMENT	PERFORM Button_Activate() FUNCTION
28	Return	DEFAULT OPERATIONS ARE NOT DEFINED	PERFORM Resume(ParentMenu) FUNCTION
29	Exit	DEFAULT OPERATIONS ARE NOT DEFINED	PERFORM Resume() FUNCTION
30	Content	DEFAULT OPERATIONS ARE NOT DEFINED	DEFAULT OPERATIONS ARE NOT DEFINED
31	Screen	NOTE 2)	DEFAULT OPERATIONS ARE NOT DEFINED
32	Focus	NOTE 3)	DEFAULT OPERATIONS ARE NOT DEFINED

FIG. 7




FIG. 8




FIG. 9




FIG. 10




FIG. 11

